Table Of Contents

SECTION 1: INTRODUCTION
1. Introduction 1-1
2. Model Compatibility 1-1
3. A Few Words About Numbering 1-1
4. Types of Numbering Heads 1-2

SECTION 2: SAFETY INSTRUCTIONS
1. Emergency & First Aid Procedures 2-1
2. Safe Operating Instructions 2-1
3. Hands-On Operations 2-1

SECTION 3: SPECIFICATIONS 3-1

SECTION 4: UNPACKING
1. Carton Inspection 4-1
2. Unpacking 4-1
3. Check List & Serial Number 4-1
4. Recommended Termperature 4-1
5. Contents Check List 4-2

SECTION 5: SETUP PROCEDURES
1. Quick Start 5-1
2. NC Insertion Instructions 5-1
3. Centering the Numbering Cylinder 5-2
4. Drive Wheel Positioning 5-4
5. Numbering Head Positioning 5-5
6. Installing the Ink Pads 5-7
7. Positioning the Actuator Cam 5-9

SECTION 6: DRIVE MECHANISM & DECLUTCHING DEVICE
1. System Overview 6-1

SECTION 7: ACTUATOR CAM SYSTEM
1. System Overview 7-1

SECTION 8: NUMBERING HEAD
1. System Overview 8-1
2. The Numbering Head 8-2
3. Installing Repeat & Skip Wheels 8-3
4. Numbering Head Maintenance 8-6
5. Numbering Head Lubrication 8-6

SECTION 9: INKING SYSTEM
1. System Overview 9-1
2. Ink Drive Wheel/Main Drive Wheel Contact 9-2

SECTION 10: TROUBLESHOOTING GUIDE.. 10-1

SECTION 11: ELECTRICAL SYSTEM
1. Wiring Diagram 11-1
2. Dip Switch Settings 11-2

SECTION 12: NC-001 PARTS LIST
1. Figure A 12-1
2. Figure B 12-2
3. Figure C 12-3
4. Accessories 12-4

SECTION 13: NC-002 PARTS LIST
1. Figure A 13-1
2. Figure B 13-2
3. Figure C 13-3
4. Accessories 13-4